


**Ship Resistance and Propulsion**  
**Prof. Dr. P. Krishna Kutty**  
**Department of Ocean Engineering**  
**Indian Institute of Technology, Madras**

**Lecture - 9**  
**Model Tests and Ship resistance Prediction Methods – II**

We have been discussing about prediction of ship resistance from model test. There are different methods for predicting the resistance from model test.

(Refer Slide Time: 00:27)



One of the method is put forward by Telfer and is known after him as Telfer's prediction method. We can see here, the graph shows total resistance coefficient usually is put as  $10^3 C_r$  because of the value of numerical values it is quite small. Usually it is better to plot you know  $10^3 C_r$  and against the Reynolds number here. So, here in the Telfer's method, it tries to satisfy a Reynolds number and a Froude number from the model test.

(Refer Slide Time: 01:12)

**Telfer's Method (contd...)**

- Telfer tried to combine the Froude's and Reynolds laws of resistance similarity.
- The specific total resistance  $\frac{R}{\rho S V^2} = f\left(\frac{V}{\sqrt{g l}}, \frac{v}{VL}\right)$
- Find out the specific total resistance  $C_T$  for geometrically similar vessels of different scale ratio (refer Fig. in previous slide) by keeping constant  $F_n$  over a range of  $R_n$ .
- Similarity at constant-length  $R_n$  the variation could be studied for a range of speed-length ratio since when  $R_n$  is constant,  $C_F$  is const.

NPTEL 6

So, here what he does is, maybe if you see the next slide it gives more better explanation for that. Telfer tried to combine as I said Froude and Reynolds law resistance similarity. There is a specific total resistance we can see that  $R$  by  $\rho S V^2$  which is representing as  $C_T$ , is going to be a function of Reynolds Froude number and Reynolds. So, what he does is find out the specific total resistance  $C_T$  from geometrically similar vessels at different scale ratio. So, uses models of different sizes, that is different scale and you find out  $C_T$  from that. Then you try to extrapolate it to the prototype.

So, here you keep that is by keeping the constant Froude number over a range of Reynolds number. You can see that here in the graph, what you consider is you consider see this is the scale of the model 50 36 25 21 18 15 and goes to finally, to the ship that is 1. So, this ship is one is to one scale. So, when it moves to this side the size of the model is coming down or you say is the smallest model, then the size of the model increases it does up to 15. Then you extrapolate the trend to that of the ship one is to one.

So, here what you have is you are considering the finding out the resistance for that model, where you keep Reynolds number constant. Constant means for the length constant Reynolds number and then you find out what is the total resistance and resistance coefficient. Then you plot it here along the this axis. Now, here since I said it is a length constant Reynolds number, you know the Reynolds number is equal to  $V L$  by  $\nu$  and where you put  $L$  is equal to constant because you have the same model. If  $V$

changes during the small range in the velocity, that is  $V$  of the model goes by the change as per the Froude assumption, that is the  $V_m$  is equal to  $V_s$  by square root of  $\lambda$ .

So, that is the variation what you see here at the this axis. So, that is what is called. So, here you get the resistance for that model at different speeds or different Froude number, actually for different Froude number you have each point is a Froude number. So, for a particular Froude number you have the resistance and you will just plot it here. Now, you go to the next model which is a bigger one the scale is 36. So, for you run the same we make the model run the model in the towing tank. Then you find out what is the at each Froude number what is that total resistance and resistance coefficient. Similarly, you do it for the different Froude number and you get this curve.

So, you repeat that for a bigger model scale 25. So, you have Froude number varying like this and you get the total resistance coefficient. Then you do for the next bigger model 21 scale, you got this curve go for the bigger one you got this curve and higher one. So, you get got a set of curves for from one curve from each model. So, which represents the total resistance coefficient. So, now what you do is you connect the points of the same Froude number here you can see the Froude number is 0.26 this line representing the 0.26 Froude number 0.25 0.23 0.22 like this, each line representing each number.

So, how you obtain got is we have the Froude number here that is 0.28, next curve you get 0.28, next curve you take another point. You join all these points you get this line this line up to 15. So, you have tested model up to a scale of 15, that is the biggest model you have tested 15 factor is equal to 15. Now, you connect this point next Froude number of 0.25, we can see this 0.25. So, you have connected the similar Froude number points we have taken up to this point. So, you have done the same thing for other Froude number. So, you get these curves up to 15.

Now, what you do is you extrapolate this curve to this value the scale of one is to one extrapolate this curve these curves to the ship that is 15 scale to the scale of one. That is the ship. So, that is how the Telfer prediction method, Telfer uses the prediction method where he tries to satisfy the Reynolds number and also the Froude number. Here you can see that this line which is given by the frictional resistance line which we have already discussed it is a Schoenherr formula frictional resistance, which we discussed in one of

the previous classes. So, this is a line representing that, it has been observed that these constant Froude number lines are following almost parallel same trend as this line.

So, he has used this as the reference line for the extrapolation of these lines to one scale. So, this is based on the observation, this line has been the following or parallel to this up to this range and we have the information for this line up to this. So, we just use this as a line parallel to that. So, that is how we got the resistance of the ship. So, here that is what he tried to combine both Froude's and Reynolds laws. We know that resistance coefficient is given by Froude number and Reynolds number is trying to satisfy both. So, here you find out the specific resistance  $\rho c t$  for geometrically similar vessels. It is not one vessel he has tried many different small model vapour model bigger model and much bigger one, of different scale ratio by keeping constant Froude number.

We have seen that is constant over a range of Reynolds number. So, we consider for the whole range of Reynolds number, here is a Froude number of curve 4.26, here is Froude number curve 4.25 like that. So, that is how what it explains here. Similarly, at constant length Reynolds number, the variation could be studied for a range of speed-length ratio since the Reynolds number is constant  $c f$  is constant. So, here that is what is done. So, here it is assumed to be a constant length Reynolds number,  $l$  is kept constant because of same model. So, this is studied for different Froude number here is this one for different Reynolds number depending on that you have this. So, he is trying to satisfy both in the same test.

(Refer Slide Time: 08:46)

**Telfer's Method (contd...)**

- Thus the only change in  $C_T$  with  $F_n$  would be due to wave-making.
- All contours of constant  $F_n$  are mutually parallel.
- $C_T$  contours of constant length  $R_n$  against  $F_n$  base are also parallel to each other (vertical slanted line in Fig.).
- Extrapolate the model values to that of the ship  $R_n$  range.
- Roughness allowance & air-resistance allowance need to be added to ship's  $C_T$  obtained by extrapolation.

NPTEL 7

Thus only change in  $C_t$  and  $C$  only change in that resistance coefficient total resistance coefficient with Froude number would be due to wave-making. So, what do you consider is only change in  $C_t$  with Froude number, if you consider along the same Reynolds number and Froude number only change is due to wave-making. All contours of constant Froude number are mutually parallel, that is what you have seen all the constant lines are see all these lines are parallel that what is mentioned here, mutually parallel  $C_t$  contours of constant length Reynolds number against Froude number these are also parallel to each other. That is these curves are also parallel these curves are also parallel to each other.

So, that is  $C_t$  contours of the constant length Reynolds number against Froude number base are also parallel to each other. That is a vertical slanted line in the figure that is what we have seen. Extrapolate the model values to that of the ship range that is what I said you extrapolated that. Then you what it is that is a model resistance then you give roughness allowance and air-resistance allowance needed to be added to ship's  $C_t$ . So, which is not present in the model test, so the roughness allowance, there is the ship model surface is more very smooth and ship surface is not so smooth.

So, the roughness is different and you have to give extra allowance to account for the variation in the roughness between the model surface and ship surface. Air resistance is not measured. So, give allowance for the air resistance also, from which you get total  $C_t$

of the ship. So, see from the  $C_t$  of the model you put these two allowances you get the  $C_t$  of the ship and obtained in the extrapolation.

(Refer Slide Time: 10:42)


Telfer's Method (contd...)

➤ The  $C_T$  curves for constant  $F_n$  is nearly parallel to the Schoenherr's flat plate formula

$$\frac{0.242}{\sqrt{C_p}} \cong \log_{10}(R_n C_F)$$

This line can therefore be used as a reference line for the parallel extrapolation.

Ship resistance is  $R_S = C_{T_s} \left( \frac{1}{2} \rho S_s V_s^2 \right)$


NPTEL
8

The  $C_t$  curves for constant Froude number is nearly parallel to the Schoenherr's formula that is what I shown before you can see here. These curves are almost parallel to this curve this is Schoenherr's formula for flat plate resistance put forward by. So, you have this formula here. So, this is isolating  $C_f$  it is not  $C_p$ . So, here you have that. So, this line can therefore, be used to reference line by the parallel extrapolation. So, this line is used the Schoenherr line is used for the parallel extrapolation because see you can if you consider you have points only up to this point.

Now, you are extrapolating a long way to the ship. So, even a small change in the trend makes a lot of difference when it reaches here. So, you do not want that to happen you minimise the error and it has been found that parallel to this which gives the trend is more reliable and hence the lines are these lines are made parallel to the Schoenherr line. So, that is this line can therefore, be used as a reference line for the parallel extrapolation. The ship resistance now you get you have got  $C_{T_s}$  from which multiplying it by half rho, the ship wetted surface area velocity square that gives the total resistance of the ship.

So, that is how the ship resistance is predicted from model test by Telfer and he tries to satisfy the Reynolds number and the Froude number in the model test, but there are a lot


of disadvantages or problems with Telfer's method, Reynolds number distance from model to ship is very large.

(Refer Slide Time: 12:47)

**Telfer's Method (contd...)**

**Problems with Telfer's method:**

- $R_T$  distance from model to ship is very large.
- Hence even a minor inaccuracy on the extrapolation can lead to large error on the forecast.
- For big models, kinematic dissimilarity around a ship model due to towing tank wall interference.
- Wall effects lead to increase in resistance.

 9

We have seen that Reynolds number which you consider from model is Reynolds number here where as the ship is not Reynolds number here. So, this is a long variation the gap is. So, high so extrapolation may lead to problems. So, that is very large and hence even a minor inaccuracy on the extrapolation can lead to large error on the forecast. So, any prediction of the ship resistance from the model test and which got extrapolated over such a gap, can lead to inaccuracy, major problem there, for big models kinematic dissimilarity around a ship model due to tank wall.

So, if you are using he has used the models say 50 to 15, when it comes to the scale of 15 the model size is. So, big the big models there is mainly the breadth of the model and it may create a tank wall effect the tank is not wide enough. This may create tank wall effect and that lead inaccurate prediction. So, hence that is what he says you see for big models kinematic dissimilarity around a ship model due to towing tank wall interference towing tank wall interferes and resistance recorded will be wrong.

(Refer Slide Time: 14:11)

**Telfer's Method (contd...)**

**Problems with Telfer's method:**

- When testing small models, flow over a large part of the model can be laminar ( $R_n$  low).
- Hence the measured resistance is less than the actual, where turbulent flow is to be encountered ( $R_n$  high for ships)
- Testing with a family of models (as a range of  $\lambda$  required) is expensive & time-consuming

NPTEL 10

Wall effects also leads increase in resistance, that is what I said wall effect again leads to increase in resistance, when testing small models so the lowest model is a scale of 50 that is a very small model. So, flow over such small models become laminar the Reynolds number is very low and the flow become laminar, which again deviates a lot from the actual flow around the ship. Hence the kinematical similarity is totally apart. So, hence the measured resistance is less than the actual, when turbulent flow is to be encountered in higher ships. So, when you consider the turbulent region and the laminar region we know that resistance coefficient is higher frictional resistance coefficient is higher and low Reynolds number or at laminar region and frictional resistance coefficient decreases when it goes to the turbulent region or in the higher Reynolds region number region.

Testing with a family of model, now what you have to do is you have seen that we are using many models. We have to have models with different scales one model with 50 scale another model with 36 scale, another model with 25 scale. So, we need so many models of different sizes, if you want to use the Telfer's method. So, model make making is expensive and time consuming. So, you can see that a testing with a family of models for a range of lambda required it is expensive and it is also time-consuming.

So, these are the disadvantages problems with the method. So, considering all these aspects disadvantages and all that and cross involvement, facility limitations many of these aspects. The method put forward by Telfer's is generally not acceptable or




practically it is not feasible. So, it is not picked up. So, we see what are the other methods available?

(Refer Slide Time: 16:17)

**Hughes' Method**

Based on experiments on frictional resistance of smooth plane surface in turbulent flow, Hughes proposed the formula

$$C_f = \frac{0.066}{(\log_{10} R_n - 2.03)^2} \sim \frac{0.067}{(\log_{10} R_n - 2)^2}$$

 11

Next method is Hughes method for the prediction of ship resistance from model test. So, based on the experiments on frictional resistance of smooth plane surface in turbulent flow Hughes proposed. So, he has considered a plane surface in turbulent flow experiments on the frictional resistance of smooth plane surface  $C_f$ . So, what he has done is this also again based on plane surface and he has come out with the plate frictional resistance based on the experiments.  $C_f$  is equal to approximate 0.067 divided by  $\log_{10} R_n$  minus to the whole square this is the expression put forward by Hughes based on his studies.

(Refer Slide Time: 17:05)

**Hughes' Method (contd...)**

**Hughes proposal**

Total resistance = Base frictional resistance (flat plate) +  
Form resistance (deeply submerged DH model) + Free  
surface resistance

= Basic frictional resistance \*  $r$  + Free surface resistance

Where  $r$  is the resistance ratio & is a constant factor for a  
given hull form  $\rightarrow r = 1 + k$ , where  $k$ =form factor


- > Fig in next slide gives  $C_T$  for different values of  $(1+k)$   
for a range of  $R_n$
- > The value of  $r$  or  $k$  can be obtained from low speed  
test (no wave-making)

NPTEL 12

So Hughes what do I put here is the total resistance is now constituted by the base frictional resistance at the flat plate which we have seen, using the previous formula plus the form resistance deeply submerged double hull model. So, double hull model is the one which I have discussed before. So, it is a deep form resistance plus free surface resistance, that is the wave-making resistance.

So, this is a basic frictional resistance into  $R$  that is the flat plate resistance into  $R$ ,  $R$  takes care of the form resistance plus the free surface resistance. Where  $r$  is the resistance ratio and is a constant factor for a given hull form. So, you find out what is  $r$  and that gives that  $r$  is equal to one plus  $k$ ,  $k$  is called the form factor. We will see in the next figure, next slide what is how this is estimated one plus  $k$  and all that.

(Refer Slide Time: 18:06)



What is that is done here, what it does is you have  $10^3 C_T$  against Reynolds number and you use the same form formula with what the Hughes formula, you can see that this is the Hughes formula. So, this with that you plot the base line the base line here you can see, that is based on this expression which is depending on Reynolds number. So, you have the Reynolds number here and you use this plot is obtained from that formula. Now, you do the model test you find out the total resistance coefficient of the model this is a model region.

So, for different Froude number different that is what different Froude number we get that resistance coefficient here. So, you plot that then you join it with a curve. So, you it goes like this basically something like this. So, this is a resistance curve. So, what you do is, now you draw lines this base line into 1.1 you get this line into base line into 1.2 you get another line, base line into 1.3 you get another line. So, you keep doing up to I think up to 1.5. So, you get so many lines which is obtained by multiplying this formula into these factors. So, you get lines which come like that.


So, now at this lower region you find that the resistance curve the model resistance curve usually goes like this it comes like this and it goes like that. So, this is a at a very low Froude number at very low Froude number the wave making effect is less. So, the major effect or the whole effect is coming from viscous. So, there is no wave making at very

low Froude number. So, at very low Froude number, if you do the test for few speeds at a very low Froude number then you get the resistance exclusively by the viscous effect.

So, if you find that this trend of the curve it is coinciding between 1.2 and 1.3 somewhere here. So, interpolate that position from which you get the form factor here. So, that is how the form factor is obtained in the from this test. So, you can see here this one k into C f that is what is marked. So, that depends on the this curve. So, k into c f represents the form factor.

So, the reason physical reason given for the from factor is that I think we have already discussed about that here the formula is based on the flat plate resistance with all this it is given thus carried out using flat plates of different length and different width in the flat plate the flow velocity around the flat plate is different from the flow velocity around the ship. So, maybe that i will explain using a diagram.

(Refer Slide Time: 21:22)



Suppose, you consider a flat plate consider as a flat plate. If you look from the top the plan view it maybe, this is a plan view it is now deeply submerged. So, you are just towing it at different speeds. Then you measure what is the force required to tow it at different speeds. So, this length is usually taken as the ship length or model length and this width is equal to half the average girth mean girth. So, both sides put together gives the total. So, this represents the wetted surface area of the ship.

Now, if you look to the from the top this is the plan. Suppose that it is moving in this way this is moving. So, that which will be the flow is in this direction. So, here the flow is like this, almost parallel flows we get. Now, you are representing this for a ship. So, you consider a ship model or ship, just consider. We just consider ship of almost same length, same length. If the flow if the ship is moving with suppose this velocity is  $v$  ship also moves with velocity  $v$ , see that because of the curvature the flow comes here because of the curvature the ship velocity increases.

The velocity here is going to be much more than this in free stream velocity. So, this increase in velocity increases the resistance of the ship because you know that frictional resistance is proportional to  $v$  power 0.825. So, this velocity is the flow velocity. So, here in the case of the ship due to this three dimensional form the flow velocity is higher which is not accounted here. So, this expression which has been developed maybe the Schoenherr's formula or Hughes formula or ITTC formula where they used a flat plate resistance. They have not considered the increase in velocity of flow due to the form of the ship. So, that increases the frictional resistance of the ship. So, which is accounted by that is why it is called the form that is  $k$  is called the form factor.

So, this  $k$  form factor is basically due to the change in the flow in the velocity or increase in the flow velocity around the ship. So, that is a physical reason for such a difference. So, that is how now you get the form factor. So, you use the same form factor for the ship also, this shows the extrapolated values of the resistance  $C_t s$  for the ship for the ship operates at a higher Reynolds number. You can see that total value from here to here it is  $1 + k$  into  $C_f s$  and  $C_f s$  is coming from this expression. So, that is what is done in the Hughes method.


So, in Hughes method what he does is he uses his the formula which I said before the same formula this is the Hughes formula for frictional resistance. Here what we say is it represents total resistance as a basic frictional flat plate resistance plus the form resistance plus free surface that is the wave making resistance. Now, he clubbed these two both are having the viscosity effect. So, we just put  $1 + k$  into the base resistance flat plate resistance plus the free surface resistance.

Now, he is suggesting how to find out  $k$  or  $1 + k$ . So, that is what is done here from the model test once we discussed, we have the base line and then using his formula of

base line. Then you generate curves with different multiplication factors 1.1 like. So, you get these curves you have the model test resistance for different Froude number we have like this something like this it comes. Curve here is not exactly matching here it will be something like this. So, that at low Froude number, you there is no wave making and the whole thing is due to viscous effect.

So, the viscous effect you see that the resistance is more than the base line. So, this more the additional resistance, this part is due to the three dimensional effect which affects due to the increase in velocity, due to the form of the ship that is why it is called the form factor. Once you get that form factor, the same form factor is taken for the ship also, with that you and then you are extrapolating with for the ship as we did before, as we suggested before. Then you get this curve and this total value what you call here it is the 1 plus k into  $C_f$  of the ship.

(Refer Slide Time: 26:45)



**Hughes' Method (contd...)**


**Steps to find ship resistance – Hughes' method**

Step1: Draw the basic line

Step2: Draw  $(1+k)$  curves for different values of  $(1+k)$  such as  $(1+k)=1.1, 1.2, \dots$

Step3: Draw curve for the model for difference speeds

Step4: The curve  $(1+k)$  having tangent common with the curve is found (the run-in-point) & there by read the  $(1+k)$  value

 NPTEL

14

So, that is the here what is what I explained draw the base line, draw 1 plus k curves for different values of that is what I suggested. Now, that like you get 1.1,1.2 factors draw the curve for the model for different speeds, that is what we have seen. Now, you have this is a model for different then the curve 1 plus k having tangent common with the curve is found to be the run point. There by reading the 1 plus k. So, what you have is this curve is goes like this actually goes like this and you find out that tangent which forms this that is the 1 plus k.

(Refer Slide Time: 27:30)

Hughes' Method (contd...)

**Steps to find ship resistance – Hughes' method**


Step5: Extrapolate the  $C_f(1+k)$  curve to the ship region

Step6: Read  $C_w$  of model at different  $F_n$  by subtracting  $C_f(1+k)$  from  $C_t$

Step7: Based on Froude's law plot  $C_w$  over  $C_f(1+k)$  to get  $C_t$  of ship

Step8: Add model-ship correlation allowance  $C_A$  to  $C_{TS}$  to account for the ship surface roughness.

Step9:  $R_{TS} = C_{TS} \left( \frac{1}{2} \rho S_z V_z^2 \right) \rightarrow (58)$




15

So, from which you read the 1 plus k. Extrapolate it  $C_f$  into 1 plus k to the ship region that is what you have done read  $C_w$  of the model at different  $F_n$  subtracting by subtracting this from the  $C_t$ . So, what you do is you here you have  $C_f$  plus k  $C_f$  and from there you find out what is the difference. That gives the  $C_w$ . So,  $C_w$  we know that is same as  $C_w$  of model same as  $C_w$  of ship. So, these two values are same only difference here this  $C_f$  value changes. So, you put  $C_f$  using this formula  $C_f$  s then you put the  $C_w$  here,  $C_w$  is constant. Put the  $C_w$  here then you get these points then you get this curve.

So, that is based on the so read a  $C_w$  model at different Froude number by subtracting  $C_f$  into 1 plus k from  $C_t$ . Based on the Froude law plot  $C_w$  over  $C_f$  into 1 plus k to get the  $C_t$  of ship. That is this I explained, add model from to this you add that model ship correlation allowance. That is I said due to the change in roughness due to the ship surface change, roughness of the ship and model are different model is very smooth whereas, for the ship it is not so smooth. The smoothness there are different reasons that also we discussed before due to painting, due to welding joints or due to deformations of the plate. There are many reasons for increase in roughness for the ship and which is not present in the case of the model. So, that increase in roughness need to be accounted when you estimate the total resistance of the ship compared to that of the model.

So, that  $C_a$  there is a correlation allowance, is added to that model value. Then you get  $C_{ts}$  and then you find out total resistance of the ship is equal to this  $C_{ts}$  value into half  $\rho S_s V_s^2$  that the ship parameters better surface and velocity and density. So you get total resistance of the ship from this that is the Hughes prediction method.

(Refer Slide Time: 29:47)



So, here that is the method which has been proposed by Hughes to estimate the form factor. Now, we see another method called Prohaska's method how to determine the form factor from the model test. So, here this is the method proposed by Prohaska in 1966. So, what he has done is the 1 plus k factor the form factor vary with respect he has given shown a curve this is for each curve for a particular  $L/\Delta^{1/3}$  you can see that. So,  $\Delta$  power one for the same length if you consider,  $\Delta$  is small,  $\Delta$  power one third isn't it.

This value will be if your  $\Delta$  is large that is fuller form then this value will be smaller. So, here it is 4 5 6 7 8 that is the value. So, this side of the curve that is when it is 4 means it is the fuller form ship. That is for the same length it has a more displacement the denominator is high, that is why the value is less. So, this region maybe referring to a tanker ship or maybe a bulk idea and all that, so these types of vessels will have higher form value. So, you can see the 1 plus k and against  $C_b$ . So, you can see the  $C_b$  value  $C_b$  is high full form and here we can see what is the form factor?



If you consider this curve the form factor is high, but when it comes to a smaller one this  $1/\Delta P$  is small that means one power is high value 8. So, here that means the denominator is small that is like container ship, whether the denominator is for the same length. The displacement is less it comes in this line you can see that form factor is less is 1 point less than 1 point 1, where here this range becomes more than 1.2. So, that shows the indication how the body is more full the higher will be the value of form factor is the body is fine because it is getting closer to that flat plate. The form factor is less, if it deviates more from the flat plate concept or assumption then the form factor effect will be more.

(Refer Slide Time: 32:23)

**Prohaska's Method (contd...)**


Prohaska proposes a method for determining the 3D form factor on flat plate friction.  $k = \frac{C_v - C_{f0}}{C_{f0}}$

$C_v$  = Total viscous resistance coefficient of the 3D form  
 $C_{f0}$  = The frictional resistance coefficient in 2D flow.

Where no separation is present,  $C_T = C_w + (1+k)C_{f0}$

$C_w$  = Wave-making resistance coefficient =  $C_w = yF_n^4 \rightarrow (61)$

$y$  = a coefficient and  $F_n$  = Froude no.

 17

Prohaska proposes a method for determining the 3 d form factor, that is what is that. He just put you put the k as the factor  $C_v$  minus  $C_{f0}$  by  $C_{f0}$ . This is the factor he used what is all this file is  $C_v$  is the total viscous resistance coefficient of the 3 d form. So, the 3 d form you consider you find out that the total viscous effect. Viscous resistance that is the  $C_v$   $C_{f0}$  is the frictional resistance of the 2 d flow that is the plate flow. So,  $C_{f0}$  is coming from the formula and  $C_v$  is actually the measured one, due to the 3 d form.

So, that difference divided by  $C_{f0}$  is given as k. So, where no separation you do not consider separation here only is the here you consider only the form effect.  $C_t$  is equal to  $C_w$  that is wave making resistance coefficient plus 1 plus k into  $C_{f0}$  that is wave making plus viscous effect. Viscous effect is  $C_{f0}$  plus this k into  $C_{f0}$  k into  $C_{f0}$  is the

difference of that means actually  $C_w$  plus  $C_v$  you can see that  $k$  is equal to  $C_v$  minus  $C_f$  divided by  $C_f$ . So, that is this gives that  $C_v$  is equal to  $k$  into  $C_f$  plus  $C_f$  that is what is written here. So, this is same as  $C_v$  which is coming from here.

So, here  $C_w$  is the wave making resistance coefficient. We already know that  $C_w$  is the function of that is  $R_w$ , you know already  $R_w$  is proportional to  $V^6$  you have derived you know the previous classes. So,  $C_w$  is equal to  $R_w$  by half  $\rho S V^2$ .

(Refer Slide Time: 34:22)

The image shows a chalkboard with the following handwritten equations:

$$C_w = \frac{1}{2} \rho S V^2$$

$$C_w \propto V^4$$

$$C_w \propto F_n^4$$


---


$$F_n = \frac{V}{\sqrt{gL}}$$

An NPTEL logo is visible in the bottom left corner of the chalkboard image.

So, that means  $C_w$  is proportional to  $C_w$  is proportional to now  $V^4$  or we know that Froude number is equal to  $V$  by root  $gL$ . So, we can say that this is now proportional to Froude number is to 4. So,  $C_w$  is proportional to Froude number raised to 4. So, that is how we have written like that  $C_w$  is  $y$ ,  $y$  is a constant into Froude number raised to  $C_w$  is proportional to Froude number raised to 4. So,  $y$  is a coefficient and  $F_n$  is the Froude number.

(Refer Slide Time: 35:08)


**Prandtl's Method (contd...)**

In the above equations,

$$R_w \propto V^6 \text{ hence } C_w = R_w / \left( \frac{1}{2} \rho S V^2 \right) \text{ is}$$

$C_w$  is proportional to  $V^4$  or  $F_n^4$


The constant of proportionality is  $y$ .

$$\frac{C_T}{C_{FO}} = (1+k) + \frac{y F_n^4}{C_{FO}}$$


18

So, in the same thing it is what I have explained  $R_w$  is proportional to  $V$  power 6 and  $C_w$  is given by this relation and from which finally, you get this proportional distribution. So, what you have is, if you look to the above relation here  $C_T$   $C_w$  and all that  $C_w$  is now is equal to  $y$  into  $F_n$  raised to 4.

(Refer Slide Time: 35:49)




$R_w \propto V^6$   
 $C_w = \frac{R_w}{\frac{1}{2} \rho S V^2}$   
 $C_w \propto V^4$   
 $C_w \propto F_n^4$

$F_n = \frac{V}{\sqrt{g L}}$

$C_T = C_w + (1+k) C_{FO}$   
 $= y F_n^4 + (1+k) C_{FO}$   
 $\frac{C_T}{C_{FO}} = (1+k) + \frac{y F_n^4}{C_{FO}}$


Diagrams showing flow over a flat plate of length  $L$  with velocity  $V$  and a boundary layer of thickness  $\frac{1}{2}$  mean gap. Below it, a diagram of a streamlined body with velocity  $V_0$ .



So, from here you write here  $C_T$  is equal to  $C_w$  into we have  $C_T$  is equal to  $C_w$  plus one plus  $k$  into  $C_{FO}$ . We know  $C_w$  is coming from here. So, that is equal to  $y$  into  $F_n$  raised to 4 plus  $1 + k$  into  $C_{FO}$  or we can write  $C_T$  by  $C_{FO}$  is equal to  $1 + k$  plus  $y$

into  $y$  or  $y F_n$  raised to 4 by  $C_{fo}$ . So, that is what we write. So, here that is what is shown you can see that  $C_t$  by  $C_{fo}$  is equal to 1 plus  $k$ . So, I think that is correct plus  $y$  this is  $y F_n$  raised to 4 by  $C_{fo}$ . So, that is how you write that expression.

(Refer Slide Time: 36:55)



So, what does that mean this is if you write this is something like a equation of a straight line  $y$  is equal to  $m x$  plus  $c$  this is  $y c$  is this is referring to  $m x$  that is if you write a if you plot a straight line with this as  $y$  and  $F_n$  raised to 4 by  $C_{fo}$  as  $x$ , then you get a straight line, so equation of a straight line. So, that is what is done you plot  $C_t$  by  $C_{fo}$  divided by against  $F_n$  raised to 4 by  $C_f$ . You get a straight line the slope of this straight line is  $y$  and intersection is equal to 1 plus  $k$ . You can see that  $C_t$  by  $C_{fo}$  is equal to 1 plus  $k$ .

So, here this is the vertical axis same as  $y$  and this is the  $x$  axis which is  $x$ . So, you see this  $y$  is equal to  $m x$  plus  $c$ . So,  $C$  is the intersection which is 1 plus  $k$ . So, you have this red dots the values coming from experiments at low Reynolds number and low Froude number. These plots for using this what you do is you find out what is  $C_t$ ,  $C_t$  is obtained the total resistance from which you get  $C_t$ . Now, you find out  $C_{fo}$  from I T T C formula or any of the formula, that is also known to you for that low Froude number.

So, you can find out this quantity and similarly, you know what is the Froude number and then the Froude number raised to 4 this also you can estimate from that model parameter. So, these two quantities are known. So, you plot this and this. Now, you get

the experimental points the red dots here, you connect of it a straight line to these points then this straight line intersects this axis and that is equal to  $1 + k$ . So, you get this value here. So, here this intersection that is how you get the intercept form factor. This is the method suggested by Prohaska.


So, you run the model at low Froude number and you get the resistance value. Then you find out what is the  $C_t$  of the model you find out what is the  $C_{fo}$  from the  $I T T C$  formula similar formula. So, you find out this ratio here. Now, you find out the model is done run at different Froude number. So, if you know that, what is the Froude number divided by the corresponding  $C_{fo}$  again from  $I T T C$ , this ratio also is obtained from the model test. Now, you plot this ratio against this ratio.

So, you get few points like this. You know this experiment you do not get just very smooth simple line. So, you just fit a straight line to that because you know that is almost following a straight line pattern linear variation, this when you put it here or extrapolate to this it intersects the axis and this intersection which is supposed by 1. So, this value directly gives 1. So, that is what is written here. So, here the model should be run at very low speed generally Froude number between 0.1 and 0.22. So, that is what is done in the Prohaska's method. That is how the models how you find out the form factor from the model test. The same form factor holds good for the ship also.

(Refer Slide Time: 40:42)

**Prohaska's Method (contd...)**


- The uncertainty of measuring resistance at very low speed is relatively large.
- This means that it is difficult to determine the "run-in-point" (see step4 in Hughes method) exactly.
- For fuller form ( $C_B \sim 0.8$ ), the plot is a concave curve.
- $(1+k)$  and  $y$  are speed dependent
- It may be better to use a power for  $F_n$  between 4 & 6 instead of 4.

 NPTEL

20

So, the uncertainty of measuring the resistance at very low speed is a relatively large. So, when you measure the resistance is very low at very small Froude number, very low speed. So, measurement become also becomes difficult when you use a small quantity. This means that it is difficult to determine the run in point that is you have seen the Hughes method what is the run-in point that is the slope which comes during the bottom.


(Refer Slide Time: 41:19)



So, the run-in point is if you consider the total resistance if you if you put a  $C_t$  against Froude number, we get a value a curve something like this. So, here and you have the  $C_f$  value,  $C_f$  coming maybe like this because you know, this is  $C_f$  and we know it is proportional to  $V$  power minus 0.175. So, it goes like this and the total resistance curve it just initially like this because this region only is the frictional resistance. Then it goes like this, wave making fix up in this region.

So, this is called the run-in point. So, this is going to be right. So, this is accounting for the form factor  $k$ . So, that is the point what it is called the run-in point. So, that is here what you see it is the run-in point, is that is the slope that reach. For fuller form that is like I mean bulk idea or the plot is concave curve, you can see that it is not it is different  $1 + k$  and are speed dependent. We see that what happens to the,  $I$  power you can see that it is not a straight line if it is a full form ship.

(Refer Slide Time: 42:50)



You can see that this is not a straight line the points you see here it is coming like a concave curve. So, it is curving like that because for fuller form ships, the resistance we have seen is generally  $V$  power 6, but for fuller form ships the resistance is not  $V$  power 6. it maybe  $V$  power 7 or  $V$  power 8. So, when you use this relation it is not going to be a straight line representation. So, what you have to do is you may have to change increase the  $F_n$  raised to 4 to  $F_n$  raised to 5 or  $F_n$  raised to 6.

Then you get a straight line otherwise you get such a curve like this. So, what is that for fuller form the plot is concave curve that is what you see  $1 + k$  and  $y$  are speed dependent it may be better to use the power for  $F_n$  between 4 and 6. So,  $F_n$  we have used previously power 4. So, here it suggests that you use something more than 4 maybe 5 or even 6.


(Refer Slide Time: 43:52)

**ITTC1957 Method**

Model total resistance,

$$C_{TM} = \frac{R_{TM}}{\frac{1}{2} \rho_M V_M^2 S_M}$$
$$C_{TM} = C_{FM} + C_{RH}$$

*ITTC formula*  $C_{FM} = \frac{0.075}{(\log_{10} R_{TM} - 2)^2}$

$$C_{RM} = C_{TM} - C_{FM} = C_{RS}$$
$$C_{TS} = C_{FS} - C_{RS} = C_{FS} + C_{RM}$$


22

So, that is how that is a Prohaska's resistance prediction method or Prohaska's method of predicting form factor not resistance actually the form factor. Then we have seen now the resistance prediction method using Telfer's and also we have seen that it is practically not acceptable. Then we have seen the Hughes method where he has considered the form factor also into effect. Next we considered the Prohaska's method to determine the form factor. So, these are the things what we have done.

Now, we have two prediction methods put forward by I T T C, initially put forward in 1957 prediction method and later it was replaced by I T T C 1978 method. So, the difference between 57 and 78 methods are, in 78 method, the form factor is also accounted for whereas, in 57 method the form factor is not considered. So, with this we will conclude the today's class and resume next day.

Thank you.